# Monitorin products

# Three-phase Asymmetry and Phase-sequence Phase-loss Relay

# K8AB-PA

# Ideal for 3-phase voltage asymmetry monitoring for industrial facilities and equipment.

- Monitor voltage asymmetry, phase sequence, and phase loss for three-phase 3-wire or 4-wire power supplies with just one Unit
- Switch setting for 3-phase 3-wire or 3-phase 4-wire power supply.
- One SPDT output relay, 6 A at 250 VAC (resistive load).
- World-wide power specifications supported by one Unit (switchable).
- Relay warning status easily monitoring using LED indicator.
- Easy wiring with ferrules
   2 × 2.5 mm<sup>2</sup> solid or 2 × 1.5 mm<sup>2</sup> standard ferrules.
- CE mark compliance certified by third party. UL certification.



CE

## **Model Number Structure**

## **■** Model Number Legend

K8AB-□□

1 2 3

1. Basic Model

K8AB: Measuring and Monitoring Relays

2. Functions

PA: Three-phase Asymmetry and Phase-sequence Phase-loss Relay.

- 3. Rated Input Voltage
  - 1: AC 115, 127, 133, 138, 200, 220, 230, 240
  - 2: AC 220, 230, 240, 277, 380, 400, 415, 480

# **Ordering Information**

### **■** List of Models

Three-phase Asymmetry and Phase-sequence Phase-loss Relay	Rated input (See note 2.)		Model
	3-phase 3-wire mode	AC 200, 220, 230, 240	K8AB-PA1
Single Statements	3-phase 4-wire mode	AC 115, 127, 133, 138	
	3-phase 3-wire mode	AC 380, 400, 415, 480	K8AB-PA2
	3-phase 4-wire mode	AC 220, 230, 240, 277	

Note: 1. Three-phase 3-wire or 4-wire and the input range are switched using a switch.

2. The power supply is shared with the rated input voltage.

# **Ratings and Specifications**

# **■** Ratings

voltage  Three-phase, four-wire mode: 115, 127, 133, 138 VAC  K8AB-PA2  Three-phase, three-wire mode: 380, 400, 415, 480 VAC Three-phase, four-wire mode: 220, 230, 240, 277 VAC  Asymmetry operation (ASY.)  Operating value setting range  Operating value  100% operation at set value Asymmetry operation will function when the difference between the highest and lowest voltage phases equals or exceeds the asymmetry operating value.  Reset (HYS.)  Hysteresis  5% of operating value (fixed)  Resetting method Automatic reset  Operating time (T)  Asymmetry  0.1 s to 30 s (Value when input rapidly changes from 0% to 120%.)  Phase sequence, phase loss 0.1 s max. (Value when input rapidly changes from 0% to 100%.)  Power ON lock (LOCK)  1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shor at this point.)  Setting accuracy  ±10% of set value (Minimum error: 50 ms)  Input frequency  45 to 65 Hz	Data diament	MOAD DAY	Three whose three wire made 200, 000, 000, 040 VAC		
K8AB-PA2  Three-phase, three-wire mode: 380, 400, 415, 480 VAC Three-phase, four-wire mode: 220, 230, 240, 277 VAC  Asymmetry operation (ASY.)  Operating value setting range  Operating value  100% operation at set value Asymmetry operation will function when the difference between the highest and lowest voltage phases equals or exceeds the asymmetry operating value.  Reset (HYS.)  Hysteresis Fesetting method Automatic reset  Operating Asymmetry  0.1 s to 30 s (Value when input rapidly changes from 0% to 120%.)  Phase sequence, phase loss  O.1 s max. (Value when input rapidly changes from 0% to 100%.)  Power ON lock (LOCK)  1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shor at this point.)  Setting accuracy  ±10% of full scale  Time error  ±10% of set value (Minimum error: 50 ms)  Input frequency  45 to 65 Hz	•				
Three-phase, four-wire mode: 220, 230, 240, 277 VAC  Asymmetry operation (ASY.)  Operating value setting range  Operating value  100% operation at set value Asymmetry operation will function when the difference between the highest and lowest voltage phases equals or exceeds the asymmetry operating value.  Reset (HYS.)  Hysteresis  5% of operating value (fixed)  Resetting method Automatic reset  Operating  Asymmetry  0.1 s to 30 s (Value when input rapidly changes from 0% to 120%.)  Phase sequence, phase loss 0.1 s max. (Value when input rapidly changes from 0% to 100%.)  Power ON lock (LOCK)  1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shor at this point.)  Setting accuracy  ±10% of full scale  Time error  ±10% of set value (Minimum error: 50 ms)  Input frequency  45 to 65 Hz	voltage		Three-phase, four-wire mode: 115, 127, 133, 138 VAC		
Asymmetry operation (ASY.)  Operating value  Index operation at set value Asymmetry operation will function when the difference between the highest and lowest voltage phases equals or exceeds the asymmetry operating value.  Reset (HYS.)  Hysteresis  Swo of operating value (fixed)  Resetting method  Automatic reset  Operating  Index operating  Operating  Asymmetry  Out s to 30 s (Value when input rapidly changes from 0% to 120%.)  Index of full scale  Time error  #10% of set value (Minimum error: 50 ms)  Input frequency  Asymmetry  Asymmetry ate: 2% to 22%  Table (CSC)  Asymmetry operation at set value Asymmetry operation at set value Asymmetry operation will function when the difference between the highest and lowest voltage phases equals or exceeds the asymmetry operating value.  Symmetry operation at set value Asymmetry operation at set value Asymmetry operation at set value Asymmetry operation at set value (Minimum error: 50 ms)  Input frequency		K8AB-PA2	Three-phase, three-wire mode: 380, 400, 415, 480 VAC		
operation (ASY.)    Poperating value   Tange   Tange					
Asymmetry operation and set value = Rated input voltage x Asymmetry set value [%] The asymmetry operation will function when the difference between the highest and lowest voltage phases equals or exceeds the asymmetry operating value.  Reset (HYS.) Hysteresis 5% of operating value (fixed) Resetting method Automatic reset  Operating time (T) Phase sequence, phase loss 0.1 s max. (Value when input rapidly changes from 0% to 120%.)  Power ON lock (LOCK) 1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shor at this point.)  Setting accuracy ±10% of set value (Minimum error: 50 ms)  Input frequency 45 to 65 Hz	operation		Asymmetry rate: 2% to 22%		
Asymmetry operating value = Rated input voltage x Asymmetry set value [%] The asymmetry operation will function when the difference between the highest and lowest voltage phases equals or exceeds the asymmetry operating value.  Reset (HYS.) Hysteresis Fesetting method Automatic reset  Operating time (T) Phase sequence, phase loss O.1 s max. (Value when input rapidly changes from 0% to 120%.) Power ON lock (LOCK)  1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shor at this point.)  Setting accuracy  ±10% of set value (Minimum error: 50 ms) Input frequency  45 to 65 Hz	(ASY.)	Operating value	100% operation at set value		
voltage phases equals or exceeds the asymmetry operating value.  Reset (HYS.) Hysteresis 5% of operating value (fixed)  Resetting method Automatic reset  Operating time (T) Asymmetry 0.1 s to 30 s (Value when input rapidly changes from 0% to 120%.)  Power ON lock (LOCK) 1 s or 5 s (Value when input rapidly changes from 0% to 100%.)  Pewer ON lock (LOCK) 1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shor at this point.)  Setting accuracy ±10% of full scale  Time error ±10% of set value (Minimum error: 50 ms)  Input frequency 45 to 65 Hz					
voltage phases equals or exceeds the asymmetry operating value.  Reset (HYS.) Hysteresis 5% of operating value (fixed)  Resetting method Automatic reset  Operating time (T) Asymmetry 0.1 s to 30 s (Value when input rapidly changes from 0% to 120%.)  Power ON lock (LOCK) 1 s or 5 s (Value when input rapidly changes from 0% to 100%.)  Pewer ON lock (LOCK) 1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shor at this point.)  Setting accuracy ±10% of full scale  Time error ±10% of set value (Minimum error: 50 ms)  Input frequency 45 to 65 Hz			The asymmetry operation will function when the difference between the highest and lowest		
Reset (HYS.) Hysteresis 5% of operating value (fixed)  Resetting method Automatic reset  Operating time (T) Asymmetry 0.1 s to 30 s (Value when input rapidly changes from 0% to 120%.)  Power ON lock (LOCK) 1 s or 5 s (Value when input rapidly changes from 0% to 100%.)  Pewer ON lock (LOCK) 1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shore at this point.)  Setting accuracy ±10% of full scale  Time error ±10% of set value (Minimum error: 50 ms)  Input frequency 45 to 65 Hz			, , , ,		
Resetting method Automatic reset  Operating time (T)  Phase sequence, phase loss O.1 s max. (Value when input rapidly changes from 0% to 120%.)  Power ON lock (LOCK)  1 s or 5 s (Value when input rapidly changes from 0% to 100%.)  Setting accuracy  ±10% of full scale  Time error  ±10% of set value (Minimum error: 50 ms)  Input frequency  45 to 65 Hz	Poset (HVS.)	Hystorosis	7 7 7		
Operating time (T)  Asymmetry  Phase sequence, phase loss  0.1 s to 30 s (Value when input rapidly changes from 0% to 120%.)  Power ON lock (LOCK)  1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shor at this point.)  Setting accuracy  ±10% of set value (Minimum error: 50 ms)  Input frequency  45 to 65 Hz	neset (n i s.)		1 0 , , ,		
time (T)  Phase sequence, phase loss  0.1 s max. (Value when input rapidly changes from 0% to 100%.)  Power ON lock (LOCK)  1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shor at this point.)  Setting accuracy  ±10% of full scale  Time error  ±10% of set value (Minimum error: 50 ms)  Input frequency  45 to 65 Hz	Resetting method		Automatic reset		
Power ON lock (LOCK)  1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shor at this point.)  Setting accuracy  ±10% of full scale  Time error  ±10% of set value (Minimum error: 50 ms)  Input frequency  45 to 65 Hz			0.1 s to 30 s (Value when input rapidly changes from 0% to 120%.)		
at this point.)           Setting accuracy         ±10% of full scale           Time error         ±10% of set value (Minimum error: 50 ms)           Input frequency         45 to 65 Hz	time (T)	Phase sequence, phase loss	0.1 s max. (Value when input rapidly changes from 0% to 100%.)		
Time error         ±10% of set value (Minimum error: 50 ms)           Input frequency         45 to 65 Hz	Power ON lock (LOCK)		1 s or 5 s (Value when input rapidly changes from 0% to 100%. The operating time is the shorte at this point.)		
Input frequency 45 to 65 Hz	Setting accuracy		±10% of full scale		
Proceedings of	Time error		±10% of set value (Minimum error: 50 ms)		
Innut impedance 100 kg min	Input frequency		45 to 65 Hz		
Imput impedance   TOU KIZ min.	Input impedance		100 kΩ min.		
Indicators Power (PWR): Green LED, Relay output (RY): Yellow LED, Alarm outputs (ALM1/2): Red LE	Indicators		Power (PWR): Green LED, Relay output (RY): Yellow LED, Alarm outputs (ALM1/2): Red LED		
Output relays One SPDT relay (6 A at 250 VAC, resistive load) , normally closed operation (normally ON)	Output relays		One SPDT relay (6 A at 250 VAC, resistive load) , normally closed operation (normally ON)		


# **■** Specifications

Ambient operating temperature		-20 to 60°C (with no condensation or icing)		
Storage temperature		-40 to 70°C (with no condensation or icing)		
Ambient operating humidity		25% to 85%		
Storage humidity		25% to 85%		
Altitude		2,000 m max.		
Voltage fluctuation ran	nge	85% to 110% of rated input voltage		
Input frequency	<u> </u>	50/60 Hz ±5 Hz (AC power supply)		
Output relays	Resistive load	6 A at 250 VAC (cos φ = 1)		
		6 A at 30 VDC (L/R = 0 ms)		
	Inductive load	1 A at 250 VAC (cos φ = 0.4)		
		1 A at 30 VDC (L/R = 7 ms)		
	Minimum load	10 mA at 5 VDC		
	Maximum contact voltage	250 VAC		
	Maximum contact current	6 A AC		
	Maximum switching	1,500 VA		
	capacity			
	Mechanical life	10,000,000 operations		
	Electrical life	Make: 50,000 times, Break: 30,000 times		
Terminal screw tighter	ning torque	1.2 N·m		
Crimp terminals		Two solid wires of 2.5 mm $^2$ , two crimp terminals of 1.5 mm $^2$ with insulation sleeves, can be tightened together		
Insulation resistance		$20~M\Omega$ (at 500 V) between charged terminals and exposed uncharged parts $20~M\Omega$ (at 500 V) between any charged terminals (i.e., between input, output, and power supply terminals)		
Degree of protection		Terminal section: IP20, Rear case: IP40		
Case color		Munsell 5Y8/1 (ivory)		
Case material		ABS resin (self-extinguishing resin) UL94-V0		
Weight		200 g		
Mounting		Mounted to DIN-rail or via M4 screws		
Dimensions		22.5 (W) x 90 (H) x 100 (D) mm		
Installation environme	nt	Overvoltage Category III, Pollution Degree 2		
Application standards		EN60255-5/-6		
Safety standards		EN60664-1		
EMC		EMI: EN61326 Industrial applications  Electromagnetic interference wave     CISPR11 Group 1, Class A: CISPR16-1/-2  Terminal interference wave voltage     CISPR11 Group 1, Class A: CISPR16-1/-2  EMS: EN61326 Industrial applications  Electrostatic discharge EN61000-4-2: 8 kV (in air)  Radiating radio-frequency electromagnetic field EN61000-4-3:     10 V/m 1 kHz sine wave amplitude modulation (80 MHz to 1 GHz)  Burst EN61000-4-4: 1 kV (I/O signal line), 2 kV (power line)  Surge EN61000-4-5: 1 kV with line (power line),     2 kV with ground (power line)  Conducted RF EN61000-4-6: 3 V (0.15 to 80 MHz)  Power frequency magnetic field immunity  EN61000-4-8: 30 A/m  Voltage dip/short interruptions  EN61000-4-11: 0.5 cycle, 0.180° each, polarity 100% (rated voltage)		

### **Connections**

### **■** Wiring Diagram

### Voltage Asymmetry and Phase Sequence/Phase Loss Operation Diagram




Note: 1. The K8AB-PA output relay is normally operative.
2. The power ON lock prevents unnecessary alarms from being generated during the instable period when the power is first turned on. There is no relay output during timer operation.

Calculating the Asymmetry Operating Voltage


Asymmetry operation condition = (Highest voltage – Lowest voltage) > Asymmetry operating voltage = Asymmetry operating voltage = Rated input voltage (V) × Asymmetry set value (%)

Note: The rated input voltage is selected and set with



### **Nomenclature**

### **■** Front




### **Indicators**

Item	Meaning
Power indicator (PWR: Green)	Lit when power is being supplied.
Relay status indicator (RY: Yellow)	Lit when relay is operating (normally lit).
Alarm indicator (ALM: Red)	Asymmetry voltage error indicator The indicator flashes to indicate the error status after the input has exceeded the threshold value while the operating time is being clocked.

### **Setting Knobs**

Item	Usage
	Used to set the asymmetry rate to 2% to 22%.
. ,	Used to set the operating time to 0.1 to 30 s.

# **■** Bottom



# **DIP Switch Functions**


		Default		
SW1	Power ON lock time	OFF	1 s	OFF
		ON	5 s	
SW2	Monitoring mode selector	OFF	3-phase 3-wire power monitoring mode	OFF
		ON	3-phase 4-wire power monitoring mode	


SW3	SW4	Fur	nction	_	Default	
			3-phase 3-wire mode	3-phase 4-wire mode	SW3	SW4
OFF	OFF	Rated input voltage switch (K8AB-PA1)	200 VAC	115 VAC		
ON	OFF		220 VAC	127 VAC	0==	0==
OFF	ON		230 VAC	133 VAC	OFF	OFF
ON	ON		240 VAC	138 VAC		
OFF	OFF	Rated input voltage switch (K8AB-PA2)	380 VAC	220 VAC		
ON	OFF		400 VAC	230 VAC	OFF	OFF
OFF	ON		415 VAC	240 VAC	OII	OH
ON	ON		480 VAC	277 VAC		

# **Dimensions**

#### K8AB-PA







# **Safety Precautions**

#### ■ Precautions for Safe Use

Make sure to follow the instructions below to ensure safety.

- 1. Do not use or keep this product in the following environments.
  - Outdoors, or places subject to direct sunlight or wearing weather.
  - Places where dust, iron powder, or corrosive gases (in particular, sulfuric or ammonia gas) exist.
  - Places subject to static electricity or inductive noise.
  - Places where water or oil come in contact with the product.
- 2. Make sure to install this product in the correct direction.
- 3. There is a remote risk of electric shock. Do not touch terminals while electricity is being supplied.
- 4. Make sure to thoroughly understand all instructions in the Instructions Manual before handling this product.
- 5. Make sure to confirm terminal makings and polarity for correct
- 6. Tighten terminal screws firmly using the following torque. Recommended torque: 0.54 N·m
- 7. Operating ambient temperature and humidity for this product must be within the indicated rating when using this product.
- There is a remote risk of explosion. Do not use this product where flammable or explosive gas exists.
- 9. Make sure that no weight rests on the product after installation.
- 10. To enable an operator to turn off this product easily, install switches or circuit breakers that conform to relevant requirements of IEC60947-1 and IEC60947-3, and label them appropriately.

#### ■ Precautions for Correct Use

#### For Proper Use

- 1. Do not use the product in the following locations.
  - Places subject to radiant heat from heat generating devices.
  - Places subject to vibrations or physical shocks.
- 2. Make sure to use setting values appropriate for the controlled object. Failure to do so can cause unintended operation, and may result in accident or corruption of the product.
- 3. Do not use thinner or similar solvent for cleaning. Use commercial
- 4. When discarding, properly dispose of the product as industrial
- 5. Only use this product within a board whose structure allows no possibility for fire to escape.

#### About Installation

- 1. When wiring, use only recommended crimp terminals.
- 2. Do not block areas around the product for proper dissipation of heat. (If you do not secure space for heat dissipation, life cycle of the product will be compromised.)
- 3. To avoid electrical shocks, make sure that power is not supplied to the product while wiring.
- 4. To avoid electrical shocks, make sure that power is not supplied to the product when performing DIP switch settings.

#### **Noise Countermeasures**

- 1. Do not install the product near devices generating strong high frequency waves or surges.
- 2. When using a noise filter, check the voltage and current and install it as close to the product as possible.
- 3. In order to prevent inductive noise, wire the lines connected to the product separately from power lines carrying high voltages or currents. Do not wire in parallel with or on the same cable as
  - Other measures for reducing noise include running lines along separate ducts and using shield lines.

### To avoid faulty operations, malfunctions, or failure, observe the following operating instructions.

- 1. When turning on the power, make sure to realize rated voltage within 1 second from the time of first supply of electricity.
- 2. Make sure to use power supply for operations, inputs, and transformer with the appropriate capacity and rated burden.
- 3. Maintenance and handling of this product may only be performed by qualified personnel.
- 4. Distortion ratio of input wave forms must be 30% or less. Use of this product with circuits that have large distortion in wave forms may result in unwanted operations.
- 5. Using this product for thyristor controls or inverters will result in
- 6. When setting the volume, adjust the control from the minimum side to the maximum side.

# **Warranty and Application Considerations**

#### Read and Understand this Catalog

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

#### **Warranty and Limitations of Liability**

#### WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

#### LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS, OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted. IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

#### **Application Considerations**

#### **SUITABILITY FOR USE**

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the products.

Take all necessary steps to determine the suitability of the product for the systems, machines, and equipment with which it will be used. Know and observe all prohibitions of use applicable to this product.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

#### **Disclaimers**

#### **PERFORMANCE DATA**

Performance data given in this catalog is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON *Warranty and Limitations of Liability.* 

#### **CHANGE IN SPECIFICATIONS**

Product specifications and accessories may be changed at any time based on improvements and other reasons. Consult with your OMRON representative at any time to confirm actual specifications of purchased product.

#### **DIMENSIONS AND WEIGHTS**

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

ALL DIMENSIONS SHOWN ARE IN MILLIMETERS.

 $To \ convert \ millimeters \ into \ inches, \ multiply \ by \ 0.03937. \ To \ convert \ grams \ into \ ounces, \ multiply \ by \ 0.03527.$ 

Cat. No. N147-E2-01

In the interest of product improvement, specifications are subject to change without notice.